
Wiring Diagram



R-Red	B-Black	G-Green	L/R-Blue/Red	G/Y-Green/Yellow	Y/R-Yellow/Red	Br-Brown	L-Blue	W-White	O-Orange
B/Br-Black/Brown	Br/L-Brown/Blue	W/G-White/Green	G/B-Green/Black	B/L-Black/Blue	Y/W-Yellow/White	G/W-Green/White	G/B-Green/Black	W/B-White/Black	L/B-Blue/Black
B/W-Black/White	B/Y-Black/Yellow	W/Y-White/Yellow	Lg-Light green	Gr-Grey	G/L-Green/Blue	G/R-Green/Red	Sb-Sky blue	W/L-White/Blue	R/W-Red/White
B/R-Black/Red	Y/B-Yellow/Black	L/W-Blue/White	Y/B-Yellow/Black	G/R-Green/Red	G/W-Green/White	Br/R-Brown/Red	L/B-Blue/Black	Br/G-Brown/Green	Lg/R-Light green/Red
L/G-Blue/Green	W/Br-White/Brown	Lg/G-Light green/Green	Lg/Y-Light green/Yellow	Lg/Br-Light green/Brown	Gr/B-Grey/Black	O/L-Orange/Blue	Sb/W-Sky blue/White	L/Br-Blue/Brown	G/P-Green/Purple

Abbreviations: MIL-Malfunction Indicator Light TPS-Throttle Position Sensor IACV-Idle Air Control Valve CPS-Crankshaft Position Sensor T-MAP=Manifold Absolute Pressure/Temperature/Manifold Absolute Pressure Sensor